










- NR 10017: FM-AM VELGER I STILLING } "AM"  
FM-AM SELECTOR IN POSITION
- NR 10051: PICKUP VELGER I STILLING } "MAGNETIC"  
PICKUP SELECTOR IN POSITION
- NR 10010: HÖYTTALERVELGER I STILLING } "MASTER 1  
LOUD SPEAKER SELECTOR IN POSITION "APP. 1  
"SEP. 2"
- NR 10011: TONEVELGER I STILLING } "HIGH FILTER"  
TONE SELECTOR IN POSITION "MÖRK"
- NR. 10052: TRYKKNAPPVENDER I STILLING: IKKE TRYKKET INN.  
PUSH-BUTTON SWITCH IN POSITION: NOT OPERATED.

\* KOMPONENTER TEGNET I PLATEFELTENE OG MERKET MED STJERNE ER IKKE MONTERET PÅ PLATENE.  
PARTS PLACED INSIDE BOARD FRAMES AND MARKED WITH AN ASTERISK ARE NOT MOUNTED ON ETCHED BOARDS.



# HULDRA 8

FRA SERIE NR. 426701



ET I PLATEFELTENE OG MERKET MED  
INTE RT PÅ PLATENE.

DO NOT MOUNT ON ETCHED BOARDS.