

TANDBERG










1972 · 73



Veiledende priser
pr. 1. februar 1973

BÅNDOPPTAKERE • RADIO/STEREOFORSTERKERE • HØYTTALERE •
FARGE- og SVART/HVITT FJERNSYN

Tandberg båndopptakere:

	Teak	Palis.	Koffertmod.
 Modell 1421 (2 spor)	1.395,—	1.395,—	
Modell 1441 (4 spor)	1.445,—	1.445,—	
Modell 1422 (2 spor)			1.495,—
Modell 1442 (4 spor)			1.545,—
Modell 1521 (2 spor)	1.495,—	1.495,—	
Modell 1541 (4 spor)	1.545,—	1.545,—	
Modell 1521-F (2 spor, F-utstyr)	2.045,—		
Modell 1521-SL (2 spor)	1.895,—		
Modell 1541-F (4 spor, F-utstyr)	2.095,—		
Modell 1522 (2 spor)			1.595,—
Modell 1522-SL (2 spor)			1.995,—
Modell 1542 (4 spor)			1.645,—
 Modell 3021X Stereo (2 spor) ..	1.795,—	1.795,—	
Modell 3041X Stereo (4 spor) ..	1.795,—	1.795,—	
 Modell 3321X Stereo (2 spor) ..	1.995,—	1.995,—	
Modell 3341X Stereo (4 spor) ..	1.995,—	1.995,—	
 Modell 2021 Stereo (2 spor) ..	1.995,—	1.995,—	
Modell 2041 Stereo (4 spor) ..	1.995,—	1.995,—	
 Modell 4021X Stereo (2 spor) ..	2.645,—	2.645,—	
Modell 4041X Stereo (4 spor) ..	2.645,—	2.645,—	
 Modell 6021X Stereo (2 spor) ..	2.695,—	2.695,—	
Modell 6041X Stereo (4 spor) ..	2.695,—	2.695,—	
 Modell 9021X Stereo (2 spor) ..	3.295,—	3.295,—	
Modell 9041X Stereo (4 spor) ..	3.295,—	3.295,—	
 TCD 300	2.195,—	2.195,—	
 Modell 11-1 (1 spor)	3.600,—		
Modell 11-2 (2 spor)	3.600,—		
Modell 11-1P (1 spor) Pilot tone	4.600,—		

Utstyr:

Mikrofon TM3	120,—
Mikrofon TM4	
Complete	185,—
Mikrofon TM4	
Handy	120,—
Mikrofon TM5	545,—
Mikrofon TM6	
Complete	195,—
Mikrofon TM6	
Handy	130,—
Mikrofon stativ TM5	95,—
Skjøtekabel TM5	55,—
Mikrofontrafo	90,—
Mikrofon Mikser	250,—
Hødetelefon HD414	198,—
Hødetlf. m/mikr. B1	365,—
Hødetlf. m/mikr. HF 230	195,—
Stetoset øretelefon	75,—
Plastdeksel	40,—
Koffert nr. 4, 5 og 6	175,—
Koffert nr. 7	195,—
Bag	130,—
Fjernstyringsenhet, 9000 X	395,—
Bildesynkr. Modell 3	380,—
Pedal	160,—
Tape head cleaner	10,—

Lydbånd

High Output - Low Noise	
LP 900 ft.	38,—
DP 1200 ft.	43,—
LP 1800 ft.	59,50
DP 2400 ft.	78,50

Kassettbånd

High Output - Low Noise	
C-60 HL	17,40
C-90 HL	23,20













Chromium Dioxide

C-60 CrO ₂	21,75
C-90 CrO ₂	29,45

Skjøtebånd	4,15
Tomspole 7"	5,15
Tomspole 5"	3,55
Tomspole 3"	1,85
Metallspole	35,—

Veske for Modell 11	160,—
Batterieliminatør 4 for Modell 11	450,—

Tandberg radio/stereo-forsterkere:

	Teak	Palis.	Eik
 Tandberg Radio Modell 42	985,—		
 Sølvsuper 11—71	1.745,—	1.745,—	1.745,—
 Sølvsuper 11—72	1.945,—	1.945,—	
 Sølvsuper 11—73	1.745,—	1.745,—	
Stereodecoder			175,—
 TA 300	1.345,—	1.345,—	
 TA 300 M	1.445,—	1.445,—	
 TR-200 FM Stereo Receiver	1.745,—	1.745,—	175,—
Stereodecoder			
 TR-200 Compact	2.245,—	2.245,—	175,—
Stereodecoder			
 TR-1000 FM Stereo Receiver	2.645,—	2.645,—	(m. stereo dec.)
 TR-1010 FM/AM	2.845,—	2.845,—	
 Huldra 10	2.845,—	2.845,—	(m. stereo dec.)
 Tandberg Portable 41			Nøttetre 895,—

Utstyr, reiseradio:

Veske	55,—	Monteringsramme for Modell 41	55,—
Batterieliminators 5 for Modell 41	110,—	Monteringskassett for Modell 41	125,—















Tandberg Hi-Fi høyttalere:

	Teak	Palis.	Eik		Teak	Palis.	Eik
Hi-Fi 11	275,—	305,—		TL 1210	395,—	440,—	395,—
Hi-Fi 12	335,—	365,—	335,—	TL 1610	495,—	565,—	
Hi-Fi 18	335,—	360,—	335,—	TL 2510	590,—	660,—	590,—
Hi-Fi 19	360,—	385,—	360,—	TL 5010	1.240,—	1.360,—	1.240,—
Hi-Fi 20	395,—	440,—	395,—				
Hi-Fi 7	440,—	495,—	440,—	Separathøyttalere:			
Hi-Fi 13	440,—	495,—		Kjøkkenhøyttaler 16	125,—		
Hi-Fi 15	845,—	915		Skolehøyttaler		Bøk	365,—

Platespillere:

Platespiller SP25 Mk III m/keramisk pick-up	475,—
Platespiller SP25 Mk III m/magnetisk pick-up	575,—
Platespiller TD-150 AB Mk II m/magnetisk pick-up	933,—
Plastdeksel for SP25	25,—
Plastdeksel for TD-150	74,—

Tandberg fjernsyn:

				Teak	Palis.
	Tandberg TV-94, 20"	m/UHF	2.295,—	
		u/UHF	2.195,—	
	Tandberg TV-84, 20"	m/UHF	2.345,—	2.445,—
		u/UHF	2.245,—	2.345,—
	Tandberg TV-85, 24"	m/UHF	2.495,—	2.595,—
		u/UHF	2.345,—	2.445,—
	Tandberg TV-86, 24"	m/UHF	2.595,—	2.695,—
		u/UHF	2.445,—	2.545,—
	Tandberg TV-87, 24"	m/UHF	2.745,—	2.845,—
		u/UHF	2.645,—	2.745,—
	Tandberg TV-88, 24"	m/UHF	2.945,—	3.095,—
		u/UHF	2.845,—	2.995,—
	Tandberg TV-89, 24"	m/UHF	3.195,—	3.345,—
		u/UHF	3.095,—	3.245,—
	Tandberg TV-95, 20"	m/UHF	2.295,—	2.395,—
		u/UHF	2.195,—	2.295,—
	Tandberg TV-96, 24"	m/UHF	2.495,—	2.595,—
		u/UHF	2.395,—	2.495,—
	Tandberg TV-97, 24"	m/UHF	2.595,—	2.695,—
		u/UHF	2.495,—	2.595,—
	Tandberg TV-98, 24"	m/UHF	2.845,—	2.995,—
		u/UHF	2.745,—	2.895,—
	Tandberg Color TV-90, 22"		6.545,—	6.545,—
	Tandberg Color TV-91, 26"		6.995,—	6.995,—
	Tandberg Color TV-92, 26"		7.295,—	7.295,—

Utstyr:

	Teak	Palis.
Bord med trinser	130,—	
Bord med trinser	130,—	160,—
Bord med trinser	130,—	160,—
Bord med trinser	130,—	160,—
Bord med trinser	130,—	160,—
Bord	120,—	147,—
Bord	120,—	147,—
Bord med trinser	Svart 130,—	
Bord med trinser	Svart 130,—	
Bord med trinser	130,—	160,—
Bord med trinser	130,—	160,—
Bord Color TV....	150,—	150,—
1 sett trinser		32,—

HANDLER: